

How to Omit Zones on a Menvier M Series Alarm

1. Enter code or swipe tag then press Ent to enter the user menu
2. The keypad will display User Level 1 press Ent or 2 – at this stage press Ent
3. The display will show User 1 Menu 1 Test Menu – press the up arrow
4. The display will show User 1 Menu 2 Omit Zones – press Ent
5. The display will show 0001 armed – type in the 4 digit zone number you want to omit or press the up or down arrow to scroll through all zones until you reach the zone you wish to omit
6. The zone number is displayed followed by Armed
7. Press the double red arrow button to change the zone status from Armed to Omitted
8. Press enter – the next zone number will display
9. Repeat the above to omit any further zones, or press Esc several times to escape all menus
10. Set the alarm as normal
11. Zone(s) are only omitted on that one setting occasion, if you want to omit the same zone(s) again (for example the following evening) you have to omit them manually again as detailed above